

SanDisk® FlashBack™ Adapter

Automatic Backup Solution

Whether your PC suffers a system failure or a full hard drive crash, the SanDisk® FlashBack™ Adapter allows you to access your content safely from a flash memory card. Designed for the millions of newer notebook computers that have an ExpressCard™ slot, the SanDisk® FlashBack™ Adapter offers a reliable, easy-to-use system to protect critical files by copying them automatically and instantly to an optional SD or SDHC card of any capacity. And with the backup card nesting completely inside the laptop, the system is literally out of sight and out of mind.



Protects your critical files against hard drive failure

- Backup critical files automatically and continuously on an SD(HC) memory card.
- Backup by folder level and file type—with password protection.
- Slides completely inside your notebook ExpressCard slot—always leave it in.

The SanDisk® FlashBack™ Adapter comes with easy-to-install software for Windows-based laptops. Once installed, the device encrypts and backs up the user's data, images, music and other files—automatically and continuously—from the computer's hard drive to the memory card. Users pre-select backup sources by individual files, folders and/or file types. The files and folders can be restored within the same folder structure as the originals and on any PC that uses Windows 2000, Windows XP or Windows Vista and has an SD card reader. The SanDisk® FlashBack™ Adapter is not needed for this process.

For protection against laptop theft and to easily share the backed-up files, the SanDisk® FlashBack™ Adapter also offers users an option for backing up content online. This is in addition to local storage on an SD card.

SanDisk®

“Set It and Forget It” System Features

- Users pre-select backup sources by individual files, folders and/or file types.
- Folders and files are automatically and continuously backed up immediately when new files are present and when changes are made to existing files and folders.
- User intervention only required when changing settings or when backed up files and folders need to be restored.
- Backed up files are encrypted to protect against unauthorized access.
- Warning message when card is 90% full and when no card is detected.
- Deleted files and folders will be kept on the backup card for up to 30 days before permanent deletion.
- Folder structure is maintained on the backup card and with restored files and folders.
- Restore individual files and folders or all files at once from card on same or any other Windows 2000/XP/Vista PC (FlashBack Adapter not required).
- Optional secured online storage to protect against laptop theft and to easily share the backed-up files (provided by BeInSync for an annual fee, more information at www.beinsync.com).